

## CASECO CORE 360° INSTALLATION INSTRUCTIONS

### METAL DISC INSTALLATION

The metal disc can be installed directly on the back of the phone or hard cases. Do not install the metal disc on soft, flexible cases.

These cases are not rigid enough to keep the disc in place.

1. Clean the back of the phone/case with a cloth making sure to Remove any dust or oils.
2. Remove the adhesive backing from the metal disc.
3. Position the metal disc in the center of the back of the device & firmly press into place.
4. Wait 10 minutes after installation for the adhesive to cure.



### CORE 360° MOUNT INSTALLATION

Before installation, test the position of the mount in a few different areas on your dash. Choose a location that is easiest for you to access by hand. Do not install the Core 360° mount on vinyl or leather surfaces. For best results, the Core 360° mount should be installed on a flat metal or plastic surface.

1. Clean the chosen area with a cloth making sure to remove any dust or oils. **NOTE: The surface must not be slippery.**
2. Remove the red adhesive backing from the Core 360° mount.
3. Position the mount on the chosen area, and press firmly into place.
4. Wait 24 hours after installation for the adhesive to cure.



### REMOVAL INSTRUCTIONS

1. Apply a few drops of rubbing alcohol between the Core 360° mount and the surface or the device it has been applied to in order to break the adhesive bond.
2. Carefully use fishing line or dental floss in a sawing motion to cut adhesive away from the surface or device. Use your finger to roll remaining adhesive off of surface.



### CAUTION!

Use of sharp edges to remove adhesive is not recommended, as it may result in scratches or damage to device and/or other surfaces!

Do not re-use 3m adhesive. Replacement adhesives can be purchased at [www.caseco.ca](http://www.caseco.ca)

- Adhesives will stick well to: Flat, hard surfaces like plastic or metal.
- Adhesives will not stick well to: vinyl, leather, rubber, or textured/rounded surfaces.
- Adhesives will not work well at temperatures above 150°F (66°C).

- All 3M™ VHB™ Tapes have a shelf life of 24 months from date of manufacture when stored at 40°F to 100°F (4°C to 38°C) and 0-95% relative humidity. The optimum storage conditions are 72°F (22°C) and 50% relative humidity.
- Ideal temperature. Recommended application temperatures are between 70°F to 100°F (21°C to 38°C).